


## Installation-SPRING

After the scheduled spring water turn on date, reconnect the meter assembly by lining it up with the unions and tightening them. Turn on the service side valve lever and check for any leaks at the unions or other joints. Tighten carefully until leak(s) stop.

Turn on the cabin side valve lever and open a cold water tap in the cabin. Let the water run for at least 2 minutes to ensure that any settled material is flushed out of the service line and the water is clear and fresh.



Complete Meter Assembly Instructions are available at [www.rmofportage.ca](http://www.rmofportage.ca)



### **RURAL MUNICIPALITY OF PORTAGE LA PRAIRIE**

**Blaine Page**

UTILITY OPERATIONS SUPERVISOR

Reservoir: (204) 267-2417 Cellular: (204) 856-6412

Fax: (204) 267-2209 Home: (204) 267-2337

Email: [bp@rmofportage.ca](mailto:bp@rmofportage.ca)

35 Tupper Street South  
Portage la Prairie, MB R1N 1W7  
Office: (204) 857-3821 Fax: (204) 239-0069

## **Delta Seasonal Cabin**

### **Water Meter Assembly Instructions**


On the scheduled date the Utility Operator will close your water service line curb stop and open the drain curb stop.

### REMOVING THE METER—FALL

Draining and Storage Procedure

At the meter assembly, ensure that the service side valve lever is open and close the cabin side valve lever.

Loosen the 2 unions (large nuts next to the valve levers) and remove the meter assembly.



Drain the water from the assembly and secure it in a heated area for the winter. If not storing in a heated area, the assembly must be blown out with compressed air to remove any traces of water.



### BLOWING OUT THE SERVICE LINE

Blow compressed air into the service line for at least 30-60 seconds to push the water out of the service line.

Close the service side valve lever so that the Utility Operator can turn the water back on in the Spring regardless of whether the meter assembly is back in place or not.



**The Municipality accepts no responsibility for damages that result if the service side valve lever is not closed when the curb stop is opened in the spring.**